

Donning Instructions

Taylortec, Inc.
The Seahorse, Type V Work Vest



Place arms through work vest one at a time making sure to have both adjustable straps under your arms and the shoulder strap over your shoulders. The stencil on the back pad should be on the inside when worn correctly.



Fasten both buckles on the front of the work vest.



Use the adjustable straps on the right side and shoulders to adjust for a snug fit.



Once your work vest is snug, secure and comfortable to wear, you're ready to go.